Your boat is equipped with a tie rod which runs from the mast collar at the deck partner to the mast step.

The tension should <u>never</u> be over tightened. The nut on deck should be finger tight with the boat at rest and the rigging

